



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
C	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	 / SOURCE
100* / →◆	-/--
◀→▶	
TV / BT/MIX	
ANT / VT/TV	
VOL+	VOL+
VOL -	VOL -
UP/PAGE+	P+
DOWN/PAGE -	P -
BRIGHTNESS+	UP
BRIGHTNESS -	DOWN
COLOR -	LEFT
COLOR+	RIGHT
→◆◀	OK
BACK / ? / S	BACK
 /  / MAG	SLEEP
 / S.T / EXEC	TV/DTV
 / GUIDE	EPG
 / EXEC	FAV
STOP / SOM / C.S	 / SMART

[illegible]