



ORIGINAL	SUPERIOR
	POWER
OUT A 1	1
OUT A 2	2
OUT A 3	3
OUT A 4	4
OUT A 5	5
OUT A 6	6
OUT A	-/--
ENTER	OK
PIP	SLEEP
SELECT	TV/DTV
ARC	EPG
A – B	FAV
OUT B 1	SHIFT+1
OUT B 2	SHIFT+2
OUT B 3	SHIFT+3
OUT B 4	SHIFT+4
OUT B 5	SHIFT+5
OUT B 6	SHIFT+6
OUT B	SHIFT+ -/--

