



ORIGINAL	REPLACEMENT
POWER	POWER
MUTE	MUTE
MENU	MENU
CLR. / CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV / AV / DVD	AV
-/-- / 10+	-/--
/ DISPLAY	
ZOOM	
MIX / ANGLE	
TEXT / AUDIO	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
	BACK
SLEEP	SLEEP
L. / R.	TV/DTV
INDEX / RETU.	INFO

ORIGINAL	REPLACEMENT
DIGEST	EPG
EQ.	FAV
PICTURE	
SLOW	
HOLD / PROG.	
RED / TITLE	RED
GREEN / SUB. T.	GREEN
YELLOW / SETUP	YELLOW
BLUE / MENU/PBC	BLUE
CANCEL / B. MARK	SHIFT+EXIT
→ P ←	SHIFT+1
→ S ←	SHIFT+2
	SHIFT+ -/--
REVEL / GO TO	SHIFT+
SIZE / A-B	SHIFT+
SKIP PREV./NEXT	SHIFT+ P-/+
REPEAT / SUB. C.	SHIFT+BACK
/ LOCK	SHIFT+EPG
RANDOM	SHIFT+FAV
EJECT	SHIFT+
PAUSE / STEP	SHIFT+
STOP	SHIFT+
F. R.	SHIFT+GREEN
PLAY	SHIFT+YELLOW
F. F.	SHIFT+BLUE

