



ORIGINAL	SUPERIOR	ORIGINAL	SUPERIOR
POWER	POWER		
MENU	MENU		
EXIT	EXIT		
1/2/3/4/5	1/2/3/4/5		
6/7/8/9/0	6/7/8/9/0		
TEXT			
VOL+	VOL+		
VOL -	VOL -		
CH+	P+		
CH -	P -		
UP	UP		
DOWN	DOWN		
LEFT	LEFT		
RIGHT	RIGHT		
OK	OK		
BACK	BACK		
INFO	INFO		
EPG	EPG		
RED	RED		
GREEN	GREEN		
YELLOW	YELLOW		
BLUE	BLUE		

