



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT NEXT	 / SOURCE
LIST	-/--
INPUT AUDIOVIDEO	
CH+	P+
CH -	P -
UP	UP
LEFT	LEFT
RIGHT	RIGHT
DOWN	DOWN
OK	OK
BACK	BACK
INPUT TV	TV/DTV
INFO	INFO
EPG	EPG
RADIO	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLU	BLU

[illegible]