



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DEV. LIST	/ AV
AUTO	-/--
TIME SHIFT	
ZOOM	
FILE LIST	
TEXT	
V+	VOL+
V-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER / GROUP	OK
RECALL	BACK
INFO	INFO
VIDEO	EPG
FAV	FAV

ORIGINAL	SUPERIOR
RED / FAV. / DAILY	RED
GREEN / DEL. / WEEK.	GREEN
YELL. / MOV. / P. INFO	YELLOW
BLUE / LOCK / TIMER	BLUE
LANG.	SHIFT+MUTE
SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV.	SHIFT+ P-
TV / RADIO	SHIFT+ TV/DTV
STOP	SHIFT+
REC	SHIFT+RED
REW	SHFIT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

