



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
RATIO	 / SOURCE
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
LAST	BACK
TV / R	TV/DTV
INFO	INFO
SLEEP	EPG
FAVOR.	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW

[illegible]