



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
TV MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	 / SOURCE
LIST	-/--
DISPLAY	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RECALL	BACK
SLEEP	SLEEP
INFO	INFO
EPG	EPG
FAV	FAV
ASPECT	 / NET TV

ORIGINAL	SUPERIOR
HOLD	 / SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
DVB MENU	SHIFT+MENU
PIC	SHIFT+1
SOUND	SHIFT+2
NICAM	SHIFT+3
SOURCE	SHIFT+ 
AUTO	SHIFT+ 
SIZE	SHIFT+ 
SUBTITLE	SHIFT+ 
SUBPAGE	SHIFT+DOWN
INDEX	SHIFT+INFO

