



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
DISPLAY	
ZOOM	
TITLE	
SUBTITLE	
VOL+	VOL+
VOL-	VOL-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
P/I	TV/DTV
VOCAL-ASSIST	INFO
PROGRAM	EPG
PBC	FAV
RED/EDIT	RED
GREEN/COPY	GREEN
YELLOW/DELETE	YELLOW
BLUE/TARGET	BLUE

ORIGINAL	SUPERIOR
SETUP	SHIFT+MENU
RANDOM	SHIFT+ -/--
ANGLE	SHIFT+
LANGUAGE	SHIFT+
SLOW	SHIFT+LEFT
RESUME	SHIFT+RIGHT
SKIP PREV.	SHIFT+ P-
SKIP NEXT	SHIFT+ P+
REPEAT	SHIFT+BACK
A-B	SHIFT+SLEEP
SEARCH	SHIFT+EPG
OPEN/CLOSE	SHIFT+
PAUSE	SHIFT+
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

