



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
TV MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	 / AV
LIST	-/--
DISPLAY	
TEXT	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RECALL	BACK
SLEEP	SLEEP
INFO	INFO
EPG	EPG
FAV	FAV
ASPECT	

ORIGINAL	SUPERIOR
HOLD	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
DVB MENU	SHIFT+MENU
PIC	SHIFT+1
SOUND	SHIFT+2
NICAM	SHIFT+3
SOURCE	SHIFT+AV
AUTO	SHIFT+ 
SIZE	SHIFT+ 
SUBTITLE	SHIFT+ 
SUBPAGE	SHIFT+DOWN
INDEX	SHIFT+INFO

