



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
OUTPUT	/ SOURCE
GO TO	-/--
VIEW	
ZOOM	
TITLE	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
STORAGE	INFO
FOLDER	FAV
RED / FILM	RED
GREEN / PHOTO	GREEN
YELLOW / MUSIC	YELLOW

ORIGINAL	SUPERIOR
BLUE / FILE	BLUE
AUDIO	SHIFT+MUTE
SETUP	SHIFT+MENU
HOME	SHIFT+EXIT
SLIDE SHOW	SHIFT+
ASPECT	SHIFT+
ROTATE	SHIFT+
PAGE+	SHIFT+UP
PAGE -	SHIFT+DOWN
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE	SHIFT+
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE
OSD	EPG
SORT	SHIFT+FAV

