



| ORIGINAL         | SUPERIOR         |
|------------------|------------------|
|                  | <b>POWER</b>     |
| <b>MUTE</b>      | <b>MUTE</b>      |
| <b>MENU</b>      | <b>MENU</b>      |
| <b>CLEAR</b>     | <b>EXIT</b>      |
| <b>1/2/3/4/5</b> | <b>1/2/3/4/5</b> |
| <b>6/7/8/9/0</b> | <b>6/7/8/9/0</b> |
| <b>SOURCE</b>    | / <b>SOURCE</b>  |
| <b>+10</b>       | <b>-/--</b>      |
| <b>QUALITY</b>   |                  |
| <b>STORAGE</b>   |                  |
| <b>COPY</b>      |                  |
| <b>EDIT</b>      |                  |
| <b>VOLUME+</b>   | <b>VOL+</b>      |
| <b>VOLUME -</b>  | <b>VOL -</b>     |
| <b>CHANNEL+</b>  | <b>P+</b>        |
| <b>CHANNEL -</b> | <b>P -</b>       |
| <b>UP</b>        | <b>UP</b>        |
| <b>DOWN</b>      | <b>DOWN</b>      |
| <b>LEFT</b>      | <b>LEFT</b>      |
| <b>RIGHT</b>     | <b>RIGHT</b>     |
| <b>ENTER</b>     | <b>OK</b>        |
| <b>RETURN</b>    | <b>BACK</b>      |
| <b>INFO</b>      | <b>INFO</b>      |
| <b>EPG</b>       | <b>EPG</b>       |
| <b>FAVORITE</b>  | <b>FAV</b>       |

| ORIGINAL                | SUPERIOR             |
|-------------------------|----------------------|
| <b>RED / TITLE</b>      | <b>RED</b>           |
| <b>GREEN / AUDIO</b>    | <b>GREEN</b>         |
| <b>YELLOW / SUB - T</b> | <b>YELLOW</b>        |
| <b>BLUE / ANGLE</b>     | <b>BLUE</b>          |
| <b>TIMER</b>            | <b>SHIFT+POWER</b>   |
| <b>OUTPUT</b>           | <b>SHIFT+ </b>       |
| <b>100</b>              | <b>SHIFT+ -/--</b>   |
| <b>SETUP</b>            | <b>SHIFT+ </b>       |
| <b>SELECT</b>           | <b>SHIFT+OK</b>      |
| <b>SKIP NEXT</b>        | <b>SHIFT+ P+</b>     |
| <b>SKIP PREV</b>        | <b>SHIFT+ P -</b>    |
| <b>REPEAT</b>           | <b>SHIFT+BACK</b>    |
| <b>DTV - T/R</b>        | <b>SHIFT+ TV/DTV</b> |
| <b>DTV - INFO</b>       | <b>SHIFT+INFO</b>    |
| <b>PAUSE</b>            | <b>SHIFT+ </b>       |
| <b>STOP</b>             | <b>SHIFT+ </b>       |
| <b>REC</b>              | <b>SHIFT+RED</b>     |
| <b>REW</b>              | <b>SHIFT+GREEN</b>   |
| <b>PLAY</b>             | <b>SHIFT+YELLOW</b>  |
| <b>FWD</b>              | <b>SHIFT+BLUE</b>    |
|                         |                      |
|                         |                      |
|                         |                      |
|                         |                      |
|                         |                      |
|                         |                      |

