



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
STAND BY	POWER
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
DISPLAY	
VOLUME UP	VOL+
VOLUME DOWN	VOL -
SKIP NEXT	P+
SKIP PREV	P -
CHECK	OK
INTRO	INFO
PROGRAM	EPG
SHUFFLE	FAV
OPEN / CLOSE	 / NET TV
PAUSE	
STOP	 / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
6 CH	SHIFT+1
AUX 1	SHIFT+2
AUX 2	SHIFT+3
CD	SHIFT+4
RIAA	SHIFT+5

[illegible]