



ORIGINAL	SUPERIOR
POWER	POWER
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
>10	-/--
DISPLAY	
ZOOM	
ANGLE	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
A – TIME	SLEEP
INTRO	INFO
CHANNEL	EPG
PROGRAM	FAV
EJECT	 / NET TV
PAUSE	
STOP	 / SMART
REW	GREEN

[illegible]