



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
MUSIC	1
OTB	2
MODE	 / SOURCE
P/N	-/--
DISPLAY	
ZOOM	
ANGLE	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
REPEAT	BACK
INTERVAL TIME	SLEEP
VIDEO	TV/DTV
PREVIEW ON/OFF	INFO
SLIDE SHOW	EPG

[illegible]