



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
GO TO	-/--
DISPLAY	
SELECT	
OPTION	
BROWSER	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
TIMESHIFT	SLEEP
TV SYSTEM	TV/DTV
COPY	INFO
GUIDE	EPG
SLOW	 / NET TV
PAUSE	

[illegible]