



ORIGINAL	SUPERIOR
POWER	POWER
AUDIO	MUTE
HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
NETFLIX	 / SOURCE
+10	-/--
PICTURE ADJUST	
ANGLE	
OPTION	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
YOUTUBE	TV/DTV
INFO	INFO
PROG. / DIRECT	EPG
RANDOM	FAV
OPEN / CLOSE	 / NET TV

ORIGINAL	SUPERIOR
PAUSE	
STOP	 / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
POP – UP MENU	SHIFT+MENU
TOP MENU	SHIFT+EXIT
SEARCH	SHIFT+ -/--
VIDEO RESOLUTION	SHIFT+ 
CALL	SHIFT+ 
SETUP	SHIFT+ 
DVD A PAGE	SHIFT+ 
REPEAT	SHIFT+BACK
A – B	SHIFT+SLEEP
DIMMER	SHIFT+INFO
DISC LAYER	SHIFT+EPG
PURE	SHIFT+FAV
RED	SHIFT+RED
GREEN	SHIFT+GREEN
YELLOW	SHIFT+YELLOW
BLUE	SHIFT+BLUE

