ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
OPTION	MENU
FAV. STATION 1	
FAV. STATION 2	
FAV. STATION 3	
VOLUME+	VOL+
VOLUME -	VOL -
CHANNEL+	P+
CHANNEL -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
BACK	BACK
SLEEP	SLEEP
INFO	INFO
RED / MUSIC	RED
GREEN / MOVIE	GREEN
YELLOW / PURE	YELLOW
BLUE / GAME	BLUE
AUX	SHIFT+1
BLU ï RAY	SHIFT+2
CBL/SAT	SHIFT+3

ORIGINAL	SUPERIOR
DVD	SHIFT+4
GAME	SHIFT+5
INTERNET RADIO	SHIFT+6
iPod/USB	SHIFT+7
NETWORK	SHIFT+8
TV AUDIO	SHIFT+9
FM	SHIFT+0
SETUP	SHIFT+
SKIP NEXT/TUNE+	SHIFT+ P+
SKIP PREV/TUNE -	SHIFT+ P -
PAGE+	SHIFT+UP
PAGE -	SHIFT+DOWN
PAUSE	SHIFT+
PLAY	SHIFT+YELLOW