



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
SET	MENU
REC MUTE	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AUX	 / SOURCE
+10	-/--
TIME DISPLAY	
CLOCK	
TIMER	
EQ MODE	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
REPEAT	BACK
SLEEP	SLEEP
REV MODE	TV/DTV
CD SRS	INFO
STOP	 / SMART VIDEO
REW	GREEN
CD PLAY/PAUSE	YELLOW
FWD	BLUE
FM/AM	SHIFT+1

[illegible]