



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DVD/DVB	 / SOURCE
>10	-/--
ANGLE/TIMER	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
TV/RADIO	TV/DTV
EPG	EPG
FAV	FAV
RED/TITLE	RED
GREEN/ZOOM	GREEN
YELLOW	YELLOW
BLUE/PROGRAM	BLUE

[illegible]