



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SAT	/ SOURCE
	-/--
PVR	
APP	
MOUSE	
TTX	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
T	SLEEP
TV / R	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
RED / F2 / AUDIO	RED
GREEN / F1	GREEN
YELLOW / F3	YELLOW
BLUE / F4 / R. LIST	BLUE
SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAGE+ / #	SHIFT+UP
PAGE - / *	SHIFT+DOWN
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE
TV	
	SHIFT+POWER
VOL+	SHIFT+ VOL+
VOL -	SHIFT+ VOL -
CH+	SHIFT+LEFT
CH -	SHIFT+RIGHT
TV / AV	SHIFT+TV/DTV

