



ORIGINAL	SUPERIOR
	POWER
	MUTE
/ MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ SAT	/ AV
LIST	-/--
MEDIA	
/ ZOOM	
HELP	
/ TELETEXT	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
END	BACK
/ TIMER	SLEEP
TV	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
EPG	EPG
HOME	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
/ SUBTITLE	SHIFT+
<	SHIFT+LEFT
>	SHIFT+RIGHT
RADIO	SHIFT+TV/DTV
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

