



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
AUDIO	MUTE
MENU	MENU
AUTO	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
DISPLAY	
GOTO	
SETUP	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
ANGLE	SLEEP
A – B	TV/DTV
TITLE	INFO
MEMO	EPG
REPEAT	FAV

[illegible]