



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
ON DEMAND	 / SOURCE
PLAYLIST	-/--
MY ACCOUNT	
	
OPTIONS	
TXT	
V+	VOL+
V -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
TV	TV/DTV
INFO	INFO
TV GUIDE	EPG

[illegible]