



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
VCR	/ SOURCE
DEV. LIST	-/--
TIME SHIFT	
ZOOM	
LANG.	
TEXT	
V+	VOL+
V -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER / GROUP	OK
RECALL	BACK
TV / RADIO	TV/DTV
INFO	INFO
EPG	EPG

ORIGINAL	SUPERIOR
FAV	FAV
AUTO	/ NET TV
RED / FAV. / DAILY	RED
GREEN / DEL. / WEEK.	GREEN
YELL. / MOV. / P. INFO	YELLOW
BLUE / LOCK / TIMER	BLUE
AUDIO	SHIFT+MUTE
FILE LIST	SHIFT+
SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

