

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
V – FORMAT	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
SLEEP	SLEEP
TV/SAT	TV/DTV
INFO	INFO
GUIDE	EPG
FAV	FAV
RED	RED
GREEN	GREEN

ORIGINAL	SUPERIOR
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
SAT	SHIFT+7
ZOOM	SHIFT+ 
OPTION	SHIFT+ 
SUBTITLE	SHIFT+ 
SLOW	SHIFT+LEFT
PAGE UP	SHIFT+UP
PAGE DOWN	SHIFT+DOWN
REPEAT	SHIFT+BACK
TV/RADIO	SHIFT+ TV/DTV
FIND	SHIFT+INFO
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

