



ORIGINAL	SUPERIOR
ON / OFF	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	 / SOURCE
PVR LIST	-/--
MARK	
OPTION	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
A-B	BACK
SLEEP	SLEEP
TV / RADIO	TV/DTV
INFO	INFO
EPG	EPG

ORIGINAL	SUPERIOR
FAV	FAV
JUMP	 / NET TV
SLOW	
RED	 RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
PIP	SHIFT+1
SWAP	SHIFT+2
MOVE	SHIFT+3
HDMI	SHIFT+ 
A – Z	SHIFT+BACK
PVR INFO	SHIFT+INFO
FAV SAT	SHIFT+FAV
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FF	SHIFT+BLUE

