



ORIGINAL	SUPERIOR
STANDBY / ON	POWER
MUTE	MUTE
POP MENU / MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MODE	/ AV
ANGLE	-/--
DISPLAY	
SOUND MODE	
SETUP	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SOURCE+	P+
SOURCE -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
SURROUND	EPG
TOP FAV	FAV

ORIGINAL	SUPERIOR
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
SEARCH	SIFT+EXIT
SKIP NEXT	SHIFT+ P+
SKIP PREV.	SHIFT+ P -
REPEAT	SHIFT+BACK
OPEN / CLOSE	SHIFT+
PAUSE	SHIFT+
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY	SHFIT+YELLOW
FWD	SHIFT+BLUE

