



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
↗ / USB	📺 / SOURCE
F1	-/--
TMS	📺
ZOOM	📺
V.FORMAT	📺
📁 / FOLDER	📺
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
↺ / RECALL	BACK
🕒	SLEEP
TV/SAT	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
RED / AUDIO	RED
GREEN / OPTION	GREEN
YELLOW / TXT	YELLOW
BLUE	BLUE
SEARCH	SHIFT+EXIT
SAT	SHIFT+7
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
TV/RADIO	SHIFT+TV/DTV
PLAY MODE	SHIFT+FAV
PAUSE	SHIFT+ ⏸
STOP	SHIFT+ ⏹
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

