



ORIGINAL	SUPERIOR
STANDBY	POWER
AUDIO	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
LIST	-/--
P. SIZE	
TEXT	
FAV+	VOL+
FAV-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
TV/DTV	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV
PAUSE	
RED	RED

[illegible]