



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SAT	 / AV
LIST	-/--
ZOOM	
TXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
SLEEP	SLEEP
PREF.	TV/DTV
INFO	INFO
GUIDE	EPG
BOOKMARK	FAV

ORIGINAL	SUPERIOR
BOOKMARK MOVE	SHIFT+FAV
SCREEN PICTURE	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REC	SHIFT+RED
PLAY	SHIFT+YELLOW
REW	SHIFT+GREEN
FWD	SHIFT+BLUE
SKIP NEXT CHAP.	SHIFT+RIGHT
SKIP PREV CHAP.	SHIFT+LEFT
RADIO	SHIFT+TV/DTV
SLOW	SHIFT+RIGHT
SUBTITLE	SHIFT+ 

