



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT NEXT	/ SOURCE
LIST	-/--
ECO	
TEXT SPLIT SCREEN	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK / CH LIST	OK
RETURN / Z	BACK
INFO	INFO
GUIDE	EPG
CEC	FAV
ZOOM	/ NET TV

ORIGINAL	SUPERIOR
RED / PAGE DOWN	RED
GREEN / PAGE UP	GREEN
YELLOW / CHAPTER	YELLOW
BLUE/ASPECT/TOPIC	BLUE
AUDIO / LANGUAGE	SHIFT+MUTE
	SHIFT+
	SHIFT+
TEXT UPDATE	SHIFT+
SUBTITLE / SUBPAGE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE / FREEZE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

