



ORIGINAL 1	ORIGINAL 2	SUPERIOR
POWER		POWER
MUTE		MUTE
TV MENU		MENU
EXIT	EXIT	EXIT
1/2/3/4/5	1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0	6/7/8/9/0
SOURCE		/ SOURCE
-/--		-/--
DISPLAY		
SIZE	---	
SUBPAGE	---	
TEXT	TXT	
VOL+/-	VOL+/-	VOL+/-
CH+/-	CH+/-	P+/-
UP	UP	UP
DOWN	DOWN	DOWN
LEFT	LEFT	LEFT
RIGHT	RIGHT	RIGHT
OK	OK	OK
	BACK	BACK
SLEEP	---	SLEEP
TV/RADIO	GOOGLE PLAY	TV/DTV
INDEX	INFO	INFO
GUIDE	EPG	EPG
FAV	---	FAV

ORIGINAL 1	ORIGINAL 2	SUPERIOR
ASPECT	NETFLIX	/ NET
---	YOUTUBE	
HOLD	PRIME VIDEO	/ SMA
RED	RED	RED
GREEN	GREEN	GREEN
YELLOW	YELLOW	YELLOW
BLUE	BLUE	BLUE
AUDIO	AUDIO	SHIFT+MU
MENU	---	SHIFT+MEI
DEL	---	SHIFT+EX
MOUSE/IR	---	SHIFT+ -/
HOME	---	SHIFT+
P.MODE	---	SHIFT+
S.MODE	---	SHIFT+
SUBTITLE	SUBT	SHIFT+
SKIP NEXT/PREV	---	SHIFT+ P+
PAGE+/-	---	SHIFT+UP/DO
ZOOM+/-	---	SHIFT+RIGHT/I
BACK	---	SHIFT+BAI
STOP	STOP	SHIFT+
REC	REC	SHIFT+REI
REW	REW	SHIFT+GREI
PLAY/PAUSE	PLAY/PAUSE	SHIFT+YELL
FWD	FWD	SHIFT+BLU

