



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
CLEAR / M4	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AVR	 / AV
6 CH.	-/--
OSD	
TUN-M	
AM / FM	
RDS	
VOL+	VOL+
VOL-	VOL-
CH+ / SLEEP	P+
CH- / SURR.	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
SET / M	OK
T/V / TEST	TV/DTV
DIRECT / M3	INFO
MEMORY	EPG
RED / GUIDE / CH.	RED
GREEN / MENU / SPKR	GREEN

ORIGINAL	SUPERIOR
YELLOW / EXIT / DIGITAL	YELLOW
BLUE / PREV CH / DELAY	BLUE
VID. 1	SHIFT+1
VID. 2	SHIFT+2
VID. 3 / D. DKIP	SHIFT+3
VID. 4	SHIFT+4
TUNING UP	SHIFT+ VOL+
TUNING DOWN	SHIFT+ VOL-
PRESET UP	SHIFT+ P+
PRESET DOWN	SHIFT+ P-
STOP / MULTI-ROOM	SHIFT+ 
REC/PAUSE / NIGHT	SHIFT+RED

