



ORIGINAL	SUPERIOR
POWER – ON	POWER
	MUTE
MENU / SPKR.	MENU
DIGITAL /	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
VIDEO TOGGLE	/ SOURCE
DELAY / NORMAL	-/--
OSD	
MEM. /	
TUN-M. /	
RDS / D. SKIP	
VOL+	VOL+
VOL -	VOL -
PR+ / SLEEP	P+
PR - / SURR.	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
SET	OK
NIGHT	SLEEP
TEST	EPG
TUNING DOWN	/ NET TV
PRESET PREV.	/ SMART

ORIGINAL	SUPERIOR
RED / TUNING UP	RED
GREEN / DIRECT	GREEN
YELLOW / CLEAR	YELLOW
BLUE / PRESET NEXT	BLUE
POWER – OFF	SHIFT+POWER
VID. 1 / VCR	SHIFT+1
VID. 2 / TV	SHIFT+2
CBL / SAT	SHIFT+3
AM / FM	SHIFT+5
6/8 CH.	SHIFT+6
CD	SHIFT+7
DVD	SHIFT+8
TAPE	SHIFT+9
CH. /	SHIFT+

