



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV / AV	 / AV
-/--	-/--
P. STD	
SWAP	
SETUP	
SCAN	
VOL+	VOL+
VOL-	VOL-
P+	P+
P-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
H. LOCK	BACK
TIME	SLEEP
DTV / TV	TV/DTV
TITLE / PBC	INFO
CALENDAR	EPG

ORIGINAL	SUPERIOR
PROGRAM	FAV
OPEN / CLOSE	
PAUSE / STEP	
STOP	
REV	GREEN
PLAY / ENTER	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
D. MENU	SHIFT+MENU
SEARCH	SHIFT+EXIT
SLOW	SHIFT+0
10+	SHIFT+ -/--
CALL	SHIFT+ 
D. CALL	SHIFT+ 
ANGLE	SHIFT+ 
CAPTION	SHIFT+ 
P+	SHIFT+ P+
P-	SHIFT+ P-
REPEAT	SHIFT+BACK
A - B	SHIFT+SLEEP

