



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
TIMER	SLEEP
INFO	INFO
GUIDE	EPG
FAV	FAV
RED / TV/SAT	RED
GREEN / TV/RADIO	REEN
YELLOW / ZOOM	YELLOW
BLUE / TV LIST	BLUE

[illegible]