



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
 / HOME	MENU
X / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
 / TV APPS	 / SOURCE
+ / PLUS	-/--
WIDE	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
 / BACK	BACK
TV / RADIO	TV/DTV
 / SEARCH	INFO
GUIDE	EPG
RED	RED
GREEN	GREEN

[illegible]