



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
LIST	-/--
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK / LISTE	OK
	BACK
TV / RADIO	TV/DTV
I	INFO
EPG	EPG
BOOKMARK	FAV
GO TO	/ NET TV
SLOW	
RED / PRO	RED

ORIGINAL	SUPERIOR
GREEN / SUBTITLE	GREEN
YELLOW / OPT.	YELLOW
BLUE / TEXT	BLUE
PIP	SHIFT+1
PIP SWAP	SHIFT+2
PIP MOVE	SHIFT+3
PIP CH.	SHIFT+4
PAGE+	SHIFT+UP
PAGE -	SHIFT+DOWN
SKIP	SHIFT+ P -
PD+	SHIFT+INFO
ARCHIVE	SHIFT+EPG
BOOKMARK LIST	SHIFT+FAV
PAUSE / TIME SHIFT	SHIFT+
STOP / LIVE/STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

