



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV / AV	 / SOURCE
SEL.	-/--
PIC. MODE	
WIDE	
	
TEXT	
VOL+	VOL+
VOL -	VOL -
P/PAGE+	P+
P/PAGE -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
SLEEP	SLEEP
TV / RADIO	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
EPG	EPG
	 / SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
SND. EFFECT	SHIFT+MUTE
OPT.+	SHIFT+MENU
	SHIFT+EXIT
PIP	SHIFT+1
POS.	SHIFT+2
SIZE	SHIFT+3
	SHIFT+ -/--
	SHIFT+ 
	SHIFT+ 
DTV SETUP	SHIFT+ 
	SHIFT+ 
	SHIFT+SLEEP
	SHIFT+INFO

