



ORIGINAL	SUPERIOR
	POWER
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
 / SOURCE	 / SOURCE
LISTA	-/--
OPZIONI	
TEXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
TV / RAD.	TV/DTV
INFO	INFO
GUIDA	EPG
MY EPG	FAV
PREMIUM / NET TV	 / NET TV
APP / mhp	 / SMART

[illegible]