



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
GAME	 / SOURCE
V+	VOL+
V -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
FWD/SUBT./ZOOM -	SLEEP
REW/TV-RADIO/ZOOM+	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV
AUTO	
RED / ZOOM	RED
GREEN / LAN/AUDIO	GREEN

[illegible]