



ORIGINAL	SUPERIOR
STANDBY	POWER
AUDIO	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
VIDEO SOURCE	 / AV
WATCH TV	-/--
DISPLAY	
ZOOM	
SETUP	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
SELECT	OK
RETURN	BACK
TIMER	SLEEP
TV / DVD	TV/DTV
TITLE	INFO
REC MODE	EPG
INSERT CHAPTER	FAV

[illegible]