



ORIGINAL	SUPERIOR
	POWER
	MUTE
/ MENU	MENU
RECALL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ MARK	-/--
/ HOME	
REC. SCHEDULE	
SUBTITLE	
	VOL+
	VOL -
CHANNEL+	P+
CHANNEL -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ RETURN	BACK
INFO	INFO
EPG	EPG
MY LIST	FAV
RED /	RED
GREEN /	GREEN

ORIGINAL	SUPERIOR
YELLOW /	YELLOW
BLUE /	BLUE
AUDIO	SHIFT+MUTE
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

