



ORIGINAL	SUPERIOR
POWER	POWER
AUDIO	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MODE	 / AV
+10	-/--
DISPLAY	
ZOOM	
ANGLE	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
REMAIN	FAV
OPEN / CLOSE	
STOP	
REW	GREEN
PLAY / PAUSE	YELLOW

[illegible]