

ORIGINAL	SUPERIOR
⏻	POWER
FADE MUTING	MUTE
MENU / CANCEL	MENU
RESUME	EXIT
CD PLAY/PAUSE	1
IPOD PLAY/PAUSE	2
TUNER PLAY/PAUSE	3
TUNER/AUDIO IN	4
CLOCK/TIMER	-/--
DISPLAY	▭
SOUND TURBO	▭
HBS	▭
BASS/TREBLE	▭
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
SET	OK
REPEAT	BACK
SLEEP/AUTO STBY	SLEEP
RANDOM	TV/DTV
DIMMER	INFO
PROGRAM	EPG

ORIGINAL	SUPERIOR
TUNER MODE	FAV
STOP/PTY SEARCH	■ / SMART
REW	GREEN
FWD	BLUE

