



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
RANDOM	-/--
A / B	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
ENTER	OK
REPEAT	BACK
SLEEP	SLEEP
DISC SKIP	TV/DTV
PROG	EPG
STOP	 / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
AUX	SHIFT+1
CD	SHIFT+2
TAPE	SHIFT+3
TUNER	SHIFT+4

[illegible]