



| ORIGINAL         | SUPERIOR  |
|------------------|-----------|
| POWER/STANDBY    | POWER     |
| MUTE             | MUTE      |
| PBC MENU         | MENU      |
| CLEAR/MEDIA      | EXIT      |
| 1/2/3/4/5        | 1/2/3/4/5 |
| 6/7/8/9/0        | 6/7/8/9/0 |
| DVD/DVB          | / SOURCE  |
| 10+              | -/--      |
| DISPLAY          |           |
| ZOOM             |           |
| SUB/MP3          |           |
| TEXT             |           |
| VOL+             | VOL+      |
| VOL -            | VOL -     |
| CH+ / SKIP NEXT  | P+        |
| CH - / SKIP PREV | P -       |
| UP               | UP        |
| DOWN             | DOWN      |
| LEFT             | LEFT      |
| RIGHT            | RIGHT     |
| ENTER            | OK        |
| RETURN           | BACK      |
| TV/R / A - B     | TV/DTV    |
| SCAN/SEARCH      | INFO      |
| EPG              | EPG       |

| ORIGINAL | SUPERIOR     |
|----------|--------------|
| DIGEST   | FAV          |
| SLOW     |              |
| RED      | RED          |
| GREEN    | GREEN        |
| YELLOW   | YELLOW       |
| BLUE     | BLUE         |
| AUDIO    | SHIFT+MUTE   |
| SETUP    | SHIFT+MENU   |
| V-MODE   | SHIFT+       |
| ANGLE    | SHIFT+       |
| TITLE    | SHIFT+       |
| REPEAT   | SHIFT+BACK   |
| STEP     | SHIFT+SLEEP  |
| N/P      | SHIFT+TV/DTV |
| EJECT    | SHIFT+       |
| STOP     | SHIFT+       |
| REC      | SHIFT+RED    |
| REW      | SHIFT+GREEN  |
| PLAY     | SHIFT+YELLOW |
| FWD      | SHIFT+BLUE   |
|          |              |
|          |              |
|          |              |
|          |              |
|          |              |

