



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
PRO LOGIC	 / SOURCE
10+	-/--
DISPLAY	
ANGLE	
P/N	
SEARCH	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
MARK	INFO
PROG	EPG
PBC	FAV

ORIGINAL	SUPERIOR
EJECT	 / NET TV
STOP	 / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
RESET	SHIFT+EXIT
3D	SHIFT+3
CHANNEL	SHIFT+ -/--
LANGUAGE	SHIFT+
ZOOM	SHIFT+ 
SETUP	SHIFT+ 
SUBTITLE	SHIFT+ 
SLOW	SHIFT+LEFT
REPEAT	SHIFT+BACK
STEP	SHIFT+SLEEP
A – B	SHIFT+ TV/DTV
TITLE	SHIFT+INFO
PSCAN	SHIFT+EPG

