



ORIGINAL	SUPERIOR
POWER	POWER
⊞ / AUDIO	MUTE
MENU / LIST	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	📺 / SOURCE
3D SURR.	-/--
DISPLAY	📺
ZOOM	📺
SETUP	📺
⋮ / SUBTITLE	📺
SKIP NEXT	P+
SKIP PREV	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
🔊 / RETURN	BACK
TIMER REC	SLEEP
TV/DVD	TV/DTV
🏠 / HOME	INFO
ANGLE	EPG
MARKER	FAV

ORIGINAL	SUPERIOR
OPEN/CLOSE	▲ / NET TV
PAUSE/STEP	⏸ / SMART TUBE
STOP	■ / SMART VIDEO
REC	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE
SEARCH	SHIFT+EXIT
CHP ADD.	SHIFT+📺
RANDOM	SHIFT+📺
DUBBING	SHIFT+📺
THUMBNAIL	SHIFT+📺
REPEAT	SHIFT+BACK
A - B	SHIFT+SLEEP
REC MODE	SHIFT+TV/DTV
TITLE	SHIFT+INFO
I SKIP	SHIFT+EPG
TIME SHIFT	SHIFT+FAV

